### CONNECTICUT FORMULA/CONVERSION TABLE

#### FORMULAS:

Alkalinity = (mL of Titrant) (Acid Normality) (50.000) mL of sample

Area = Length X Width

= .785 X (Diameter)<sup>2</sup>

= 1/2 X Base X Height

Chemical Feed Pump Setting, % Stroke = Desired Flow X 100% Maximum Flow

Circumference = 3.14 X Diameter

Composite Sample Single Portion = (Instantaneous Flow) (Total Sample Volume)
(Number of Portions) (Average Flow)

**Detention Time** =  $\frac{\text{Volume}}{\text{Flow}}$ 

Discharge = Volume Time

Dosage, LBS/Day =  $mg/L \times 8.34 \times MGD$ 

Efficiency =  $\frac{\text{In-Out}}{\text{In}}$  X 100

Filter Backwash Rate = Flow Filter Area

 $\mathbf{GPCD} = \underbrace{\mathbf{GPD}}_{\mathbf{Population}}$ 

Hardness = (mL of Titrant) (1,000)mL of sample

**Horsepower** =  $\underline{\text{Flow (GPM) X Head (FT)}}$  3960

Hydraulic Loading Rate =  $\frac{\text{Flow}}{\text{Area}}$ 

% Reduction in Flow = (Original Flow - Reduced Flow) X 100
Original Flow

 $Slope = \underline{Drop \ or \ Rise}$  Distance

# Surface Loading Rate = Flow Area

#### **CONVERSION FACTORS:**

7.5 GAL/CF

8.34 LBS/GAL

2.31 Feet of Head/PSI

## **ABBREVIATIONS:**

C

-	
CF	Cubic Feet
CFS	Cubic Feet per Second
F	Fahrenheit <sup>1</sup>
GAL	Gallons
GPM	Gallons per Minute
GPD	Gallons per Day
LBS	Pounds
mL	Mililiter
mg/L	Miligrams per Liter
MGD	Million Gallons per Day
SF	Square Feet
PPM	Parts per Million
GPG	Grains per Gallon
PSI	Pounds per Square Inch

Celsius

#### FORMULAS:

$$(^{\circ} \text{ C x } 9/5) + 32 = ^{\circ} \text{ F}$$

$$(^{\circ} F - 32) \times 5/9 = ^{\circ} C$$